### MS Qwizard - Release Notes

#### Version 2.00 - 05/12/2018

Undo functionality.

Dragging an image out of the layout will remove it from the layout itself.

Consistency check of images database at startup.

Maintenance commands double clicking on the storage space panel.

Fix to Red Screen Of Death printing some long images.

#### Version 1.38 - 19/09/2018

Fixed to wrong disk free space computation Fixed to unexpected info message clicking on ruler

### Version 1.36 - 14/09/2018

Layout max number of copies changed from 500 to 5000.

Some debug information added.

Fixed an error happening when dragging the "Receiving job"

Fixed an error while receiving a job. If the connection get lost (i.e. cable disconnected) the receiving job lock into the receiving queue and is not possible to remove it anymore.

When reloading a layout the printing mode was not restored correctly.

Media width: previously, at startup, it was reset to the width of the machine, now is set to the last value entered by the operator.

There is now an information message trying to load a print job not compatible with the printer current setting.

The job is aborted if the RIP does not send image data for more than 10 seconds

Fixed an issue creating white lines between the tile of a repeat.

Fixed to wrong disk usage panel

# Version 1.32 – 10<sup>th</sup> May 2018

Bug fix: the images contained in a printed layout have been reloaded using the RIP origin setting instead the printing position

# Version 1.30 - 07<sup>th</sup> May 2018

Bug fix for the Step&Repeat feature

# Version 1.26 - 03th Apr 2018

New feature Step&Repeat: double click over any image in the layout permits to set step and repeat parameters.

### Version 1.24 - 20th February 2018

Fix to some situation hanging the software on print job abort from printer side.

### **Version 1.22 – 16th February 2018**

Fix to several situation hanging the software on print job end.

### Version 1.20 - 02<sup>nd</sup> February 2018

Fix to several situation hanging the software when stopping or terminating a print job.

### Version 1.14 - 10th November 2017

Fix to alignment lines display when layout window origin is not equal zero Multiple selection toolbar disappear if multiple selection count reach zero Fix to an hang during print job abort (from either Qwizard or Printer)

Fix to job abort from RIP side

Rulers font changed to better fit

Fix a GUI mistake when changing the display mode of the source queue while receiving a job An incomplete job is automatically removed from the queue.

Fix a deadlock happening while receiving a job and scroll a list view.

The total length of the layout is shown on the bottom part of the vertical ruler.

Added two arrows in the vertical ruler to move to top/bottom of the layout.

# Version 1.12 – 22th September 2017

Additional fix to A and B mode mismatch with some command sequence Fix to image alignment in layout window

# Version 1.10 – 13th September 2017

The behavior for the multiple selection has been changed: on the selection of the first element, using long-press, the software shows a toolbar on top of the relative queue showing the various action possible for the items. There is also a button to select and unselect all the items.

There was a mismatch in the print mode when receiving print jobs with 3 dpd with specific dotmap: as a result most B print modes were recognized as A mode.

The print mode selection menu now correcly handle the print modes @s, As and Bs.